


# SNOOPY SNO-CONE MACHINE INSTRUCTIONS

Your SNOOPY Sno-Cone Machine shaves ordinary ice cubes into snow! Scoop out the snow and place it in the cups. Flavor with the FLA-VOR-AID® syrup, and you've created delicious Sno-Cone treats for you and your friends! All you have to do is follow these simple directions. But before you do, take a look at the illustration so you become familiar with the parts of your Sno-Cone Machine. Be sure to wash all parts of the Sno-Cone Machine thoroughly in warm water before using. **DO NOT PLACE IN DISHWASHER.**



SNOOPY



FRONT VIEW

SIDE VIEW


INSERT THRU FRONT ONLY

1



ICE SHAVER

2




SHAVER HANDLE

3



LOCKING CAP



ICE CUBE CHUTE

SYRUP BOTTLE


SNOOPY SNO-CONES

SCOOP

INSERT SO SNOO  
FACES IN THIS DIR  
TION ONLY! FEET  
FACING FRONT.

## IMPORTANT NOTE: PLEASE READ CAREFULLY

- 1 Insert small end of Ice shaver thru front opening ONLY of Sno-Cone Machine.
- 2 Hold ice shaver in place and fit handle notches over two tabs on rim of ice shaver at the rear of the machine.
- 3 While holding front rim of ice shaver, fit locking cap into handle and turn clockwise to lock in place.



REAR VIEW



ANTI-SKID PADS

BOTTOM VIEW

POSITION THE 4 ANTI-SKID PAD LABELS TO THE BOTTOM OF THE SNO-CONE MACHINE AS ILLUSTRATED.

# HOW TO MAKE SNO-CONES

1. First follow the recipe below to make your flavoring syrup. 1 Envelope **FLA-VOR-AID®** unsweetened, soft drink mix, and flavor. 1 cup of sugar (or to taste) ½ cup of water.

Combine **FLA-VOR-AID®** sugar and water in mixing bowl. Stir until **FLA-VOR-AID®** and sugar are dissolved.

Remove top of syrup bottle and pour syrup carefully into bottle. Replace top.

2. Insert small end of the ice shaver through the front opening **ONLY** of the SNO-CONE Machine. Place fingers over the front rim of shaver as you fit handle notches over the two tabs on the rim of the ice shaver at the rear of the machine. While holding front rim of the shaver, fit locking cap into the handle and turn clockwise to lock in place.

3. Lift out **SNOOPY** and drop **ONE** ice cube into the ice chute. **VERY IMPORTANT** — Replace **SNOOPY** (See drawing on other side) so his feet face towards front of machine. **NOTE: USE ONLY ONE ICE CUBE AT A TIME.**
4. Turn shaver handle clockwise about six times without applying any pressure on **SNOOPY**. Now, while turning clockwise, apply pressure on **SNOOPY** and ice shaving will begin.

Applying pressure on **SNOOPY** before turning shaver handle may cause jamming and damage to the shaver. Therefore, it is advisable to turn shaver handle first, then slowly apply pressure on **SNOOPY**. You will notice that the handle will turn easily or hard depending on the amount of pressure you apply to **SNOOPY**. With a little practice, you will learn to apply just the right amount of pressure. Keep turning the handle clockwise until the ice cube is used up.

5. Take the scoop, and shovel out the ice shavings into the paper cups.
6. Sprinkle with enough flavoring to saturate the ice shavings. All done and ready to eat!
7. To clean your Sno-Cone Machine, simply rinse with warm (not hot) water and wipe dry. If further cleaning is desired, you can remove shaver handle and ice shaver from machine. After each use, shake out any water or ice particles that may have accumulated in machine.

## SUGGESTIONS

Additional packets of **FLA-VOR-AID®** may be purchased at your favorite supermarket or grocery store.

Or you may want to try filling an ice cube tray with lemonade or any real fruit juice and freezing it. Now place the cubes, one at a time, into the machine and grate. This way you can make flavored snow with or without extra syrup flavoring.

PEANUTS Characters ©1950, 1952, 1958, 1965 United Feature Syndicate, Inc.  
FLA-VOR-AID® mfd. by the Jel Sert Company, West Chicago, Illinois 60185

1979 Hasbro Industries, Inc., Pawtucket, R.I. 02861 U.S.A.

Printed in U.S.A.

